

## BCF 550 Brushcutter



### Documents

Engine

Starter assy

Tank and air filter

Transmission

Frame


Accessories

Carburetor WT-1199

Illustrated parts list (Head "Load and Go" Ø130)



[WWW.LOBEST.HU](http://WWW.LOBEST.HU)



Kertigépek és alkatrészek


WWW.LOBEST.HU

## Illustration Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	7	3891048R	Screw				
2	1	61400033AR	Muffler cover				
3	1	61402053BR	Muffler assy				
4	2	3891086R	Screw				
5	2	3819010R	Washer				
6	2	3916006R	Washer				
7	1	61400038BR	Deflector				
8	1	3819006R	Washer				
10	1	61400139R	Cylinder cover				
11	1	3055118R	Spark plug				
13	2	3893016AR	Screw				
14	8	3991009R	Screw				
15	1	61400005R	Gasket				
16	6	4138242R	Bushing				
17	1	61400016R	Gasket				
18	2	50080013R	Piston ring				
19	1	006000012R	Piston pin				
20	1	61400182	Piston assy				
21	1	61400181	Complete cylinder Ø45				
22	4	3891054R	Screw				
23	2	3050001R	Seal ring				
24	2	3025022R	Snap ring				
25	2	3034012R	Bearing				
26	1	61400039R	Crankshaft				
27	1	026400017R	Bearing				
28	1	61400010AR	Crankcase assy				
29	1	61400194R	Short block				
30	1	61400183	Gasket set				
31	1	61400296R	Cover				

WWW.LOBEST.HU

Illustration Starter Assy



**LOBEST** Kft.  
Kertigépek és alkatrészek

[WWW.LOBEST.HU](http://WWW.LOBEST.HU)


## Illustration Starter assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	3891053R	Screw				
2	1	2501014R	Ignition coil				
3	1	61400070R	Spark plug cap				
4	1	61400040R	Spacer				
5	1	61250282AR	Cable				
6	1	004000142R	Nut				
7	1	3833080R	Washer				
8	1	3916009R	Washer				
9	1	61400087R	Flywheel				
10	1	61402007R	Clutch driver				
11	2	3024007R	Ring				
12	2	3064010R	Washer				
13	2	61400024R	Spring				
14	2	61400023R	Pawl				
15	1	61350342R	Screw				
16	1	61400212R	Sprocket				
17	1	61400021R	Spring				
18	1	61400020R	Starter pulley				
19	1	004000132R	Spring				
20	1	4098073R	Starter rope				
21	1	072700089R	Bushing				
22	1	62030011R	Starter handle				
23	1	61402089AR	Starter assy				
24	4	3891048R	Screw				
25	2	3818011AR	Washer				
26	1	4191153BR	Clutch				
27	1	4191028R	Spring				
28	1	61420020	Fitment system				
29	1	62010005R	Pin				
30	1	62010001AR	Adapter				
31	1	4193005R	Clutch drum				
32	1	3025022R	Snap ring				
33	1	3035042R	Bearing				
34	1	3024015R	Ring				
35	1	61400055AR	Starter case				
36	1	61400057AR	Guard				
37	1	3049021R	O-ring				
38	1	61400299R	Blower				

**Best** Kft.  
Kertigépek és alkatrészek

WWW.LOBEST.HU

# Illustration Tank and air filter




**L • Best** Kft.  
Kertigépek és alkatrészek

[WWW.LOBEST.HU](http://WWW.LOBEST.HU)

## Illustration Tank and air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	6140007R	Gasket				
2	1	61400191	Insulator				
3	8	3891048R	Screw				
4	1	61400027R	Gasket				
5	1	2318662BR	Carburetor				
6	1	61400056AR	Gasket				
7	1	3960017AR	Screw				
7	3	3960087AR	Screw				
8	1	61400123BR	Starter lever				
9	2	3960145R	Screw				
10	1	61400341A	Air filter support set				BT3-155-01/23
12	2	3916005R	Washer				
13	2	3833073R	Washer				
14	2	3891063R	Screw				
16	1	61330040AR	Screw				
17	1	61400343	Complete tank				
18	1	61070011AR	Breather valve				
19	1	61380111R	Breather fuel pipe				
20	1	61380112R	Tube				
21	1	3073021AR	Tube				
22	1	4161211R	Bush				
23	1	61400183	Gasket set				
24	1	61070079AR	Tank cap				
25	1	61070006R	Gasket				
26	1	61110162BR	Bushing				
27	1	61400322R	Fuel filter				
28	1	61400136R	Insert				
30	4	3918010R	Washer				
31	4	3819006R	Washer				
32	1	61400229R	Air filter				
33	1	61400261A	Air filter cover + air filter				
34	1	61400347	Diode Kit				
35	4	61400321R	Spacer				
36	4	3891057R	Screw				



**LOBEST** Kft.  
Kertigépek és alkatrészek

[WWW.LOBEST.HU](http://WWW.LOBEST.HU)



## Illustration Transmission

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61380094	Guard				
2	2	3891051R	Screw				
3	1	4179198AR	Spacer and clamps				
4	1	62030042R	Drive shaft				
5	1	61400388R	Tube				
6	1	3045034R	Retainer washer				
7	1	3901008R	Screw				
8	1	3024010R	Snap ring				
9	1	3025018R	Ring				
10	1	3035230R	Bearing				
11	1	3034008R	Bearing				
12	1	4138311A	Ring				
13	1	3025009	Ring				
14	1	3901016	Screw				
15	1	61040071R	Cap				
16	1	61050013R	Gear case				
17	1	3034218R	Bearing				
18	1	61250054R	Pin				
19	1	3034012R	Bearing				
20	1	3025022R	Snap ring				
21	1	3050018R	Seal ring				
22	1	61040066R	Spacer				
23	1	61040145R	Hub				
24	1	4179089R	Flange				
25	1	61110074AR	Guard				
26	1	61110075R	Nut				
27	1	61250237A	Set bevel gear Ø26 + insert				
28	1	61040132A	Bevel gear set				
29	1	62030051R	Ring nut				
30	1	3049074R	O-ring				
31	7	3893016AR	Screw				
32	1	62030056AR	Screw				
33	1	3914006R	Nut				
34	1	61400337R	Cable				
35	1	61400336R	Throttle cable				
36	2	3049046R	O-ring				
37	1	61380055AR	Lever				
38	1	61400155AR	Button				
39	1	4100098BR	Spring				
40	1	61400158R	Throttle lever				
42	2	3960061AR	Screw				
44	1	62030049	Spring				
46	2	3918003R	Washer				
47	1	3033021	Pin				

**Best** Kft.  
Kertigépek és alkatrészek



WWW.LOBEST.HU

## Illustration Transmission

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
48	1	61400168R	Button				
49	1	61400219AR	Pawl				
51	1	61380093	Complete knob				
52	1	61402099R	Complete handle				
53	1	3050034R	Seal ring				
54	2	3034019R	Bearing				
55	1	62030090AR	Joint				
56	1	62030023R	Bushing				
57	2	3049008R	O-ring				
58	1	4137005DR	Drive shaft				
59	1	62030093ER	Flexible shaft				
60	1	62030077R	Band				
61	4	3891057R	Screw				
62	1	61010024R	Clamp				



[WWW.LOBEST.HU](http://WWW.LOBEST.HU)



**LOBEST** Kft.  
Kertigépek és alkatrészek






[WWW.LOBEST.HU](http://WWW.LOBEST.HU)

## Illustration Frame

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61400257AR	Frame				
2	1	61400317R	Support				
3	1	61400260AR	Cover				
4	1	61400256R	Spacer				
5	1	3910029R	Screw				
6	1	3035008R	Bearing				
7	1	365000070	Nut				
8	1	61400315R	Spacer				
9	1	61400265R	Flange				
10	3	3914003R	Nut				
11	5	3891036R	Screw				
12	6	3918020R	Washer				
13	4	3892002R	Screw				
14	4	61400316R	Spring support				
15	4	3891057R	Screw				
16	4	61400290R	Spring				
17	1	61400263AR	Harness				



[WWW.LOBEST.HU](http://WWW.LOBEST.HU)



**Best** Kft.

Kertgépek és alkatrészek


[WWW.LOBEST.HU](http://WWW.LOBEST.HU)

## Illustration Accessories

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	3960040R	Screw				
2	1	4174278R	Plate				
3	4	3802004DR	Screw				
4	1	61332032R	Skirt w/blade				
5	1	4174275R	Blade				
6	1	61280332	Guard				
7	1	61052031R	Tool kit				
8	1	61400192	Labels kit				
9	1	4095673BR	3-tooth blade				



[WWW.LOBEST.HU](http://WWW.LOBEST.HU)



[WWW.LOBEST.HU](http://WWW.LOBEST.HU)


## Illustration Carburetor WT-1199

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318643R	Adjust. screw MAX				
2	1	2318671	Repair kit				
3	1	2318662BR	Carburetor				
4	1	3052036R	Special screwdriver "D-style" type				
5	1	2304001R	Special screwdriver KNURL-STYLE				EI02-02_22



[WWW.LOBEST.HU](http://WWW.LOBEST.HU)





## Illustration Illustrated parts list (Head "Load and Go" Ø130)

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	63129015	Head Load&Go			ExtraLife	
1	1	63129008	Head Load&Go			Easy&LongLife	
2	1	63120041R	Insert				
3	1	63120040R	Nut				
4	1	63120031R	Kit spring				
5	1	63120020AR	Ignition coil				
6	1	63120030AR	Knob			ExtraLife	
6	1	63120007AR	Knob			Easy&LongLife	
7	2	63120001R	Bushing				
8	1	63120005R	Cover				



[WWW.LOBEST.HU](http://WWW.LOBEST.HU)