

BC 530 T Brushcutter



Documents

Engine

Ignition system

Tank and air filter

Transmission


Accessories

Carburetor WT-1199

Illustrated parts list (Head "Load and Go" Ø130)



WWW.LOBEST.HU



LOBEST Kft.
Kertigépek és alkatrészek


WWW.LOBEST.HU

Illustration Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	7	3891048R	Screw				
2	1	61400033AR	Muffler cover				
3	1	61402053BR	Muffler assy				
4	2	3891086R	Screw				
5	2	3819010R	Washer				
6	2	3916006R	Washer				
7	1	61400038BR	Deflector				
8	1	3819006R	Washer				
10	1	61400139R	Cylinder cover				
11	1	3055118R	Spark plug				
12	1	61400071AR	Cover				
13	2	3893016AR	Screw				
14	8	3991009R	Screw				
15	1	61400005R	Gasket				
16	6	4138242R	Bushing				
17	1	61400016R	Gasket				
18	2	50080013R	Piston ring				
19	1	006000012R	Piston pin				
20	1	61400182	Piston assy				
21	1	61400181	Complete cylinder Ø45				
22	4	3891054R	Screw				
23	2	3050001R	Seal ring				
24	2	3025022R	Snap ring				
25	2	3034012R	Bearing				
26	1	61400039R	Crankshaft				
27	1	026400017R	Bearing				
28	1	61400010AR	Crankcase assy				
29	1	61400194R	Short block				
30	1	61400183	Gasket set				
31	1	61400296R	Cover				

WWW.LOBEST.HU

Illustration Ignition system




LOBEST Kft.
Kertigépek és alkatrészek

WWW.LOBEST.HU

Illustration Ignition system

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	3891053R	Screw				
2	1	2501007R	Ignition coil				
3	1	61400070R	Spark plug cap				
4	1	61400040R	Spacer				
5	1	61250282AR	Cable				
6	1	004000142R	Nut				
7	1	3833080R	Washer				
8	1	3916009R	Washer				
9	1	61400087R	Flywheel				
10	1	61402007R	Clutch driver				
11	2	3024007R	Ring				
12	2	3064010R	Washer				
13	2	61400024R	Spring				
14	2	61400023R	Pawl				
15	1	61350342R	Screw	SN 2848030041			BT3-142-07/18
15	1	3893063R	Screw		SN 2848030040		BT3-142-07/18
16	1	61400212R	Sprocket				
17	1	61400021R	Spring				
18	1	61400020R	Starter pulley				
19	1	004000132R	Spring				
20	1	4098073R	Starter rope				
21	1	072700089R	Bushing				
22	1	61200015R	Starter handle				
23	1	61402091R	Starter assy	SN 2848030041			BT3-142-07/18
24	4	3891048R	Screw				
25	2	3818011AR	Washer				
26	1	4191153BR	Clutch				
27	1	4191028R	Spring				
28	1	61420020	Fitment system				
29	1	61040017R	Adaptor				
30	2	3914003R	Nut				
31	1	61250105R	Clutch drum				
32	1	3025022R	Snap ring				
33	1	3035042R	Bearing				
34	1	3024015R	Ring				
35	1	61400055AR	Starter case				
36	1	61400057AR	Guard				
37	1	61040010R	Sleeve				
38	1	61400135R	Bushing				
39	2	3801016R	Screw				
40	1	61040017R	Adaptor				

Illustration Tank and air filter




Kertigépek és alkatrészek

WWW.LOBEST.HU

Illustration Tank and air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61400007R	Gasket				
2	1	61400191	Insulator				
3	4	3891048R	Screw				
4	1	61400027R	Gasket				
5	1	2318662BR	Carburetor				
6	1	61400056AR	Gasket				
7	1	3960017AR	Screw				
7	3	3960087AR	Screw				
8	1	61400123BR	Starter lever				
9	2	3960145R	Screw				
10	1	61400342A	Air filter support set		Maggio 2020 / May 2020		BT3-146-05/20,
10	1	61400342A	Air filter support set	Giugno 2020 / June			BT3-155-01/23, BT3-146-05/20,
11	1	61400261A	Air filter cover + air filter		SN 2848079999		BT3-140-03/18
12	2	3916005R	Washer				
13	2	3833073R	Washer				
14	2	3891063R	Screw				
15	1	61400261A	Air filter cover + air filter		SN 2848079999		BT3-140-03/18
16	1	61330040AR	Screw				
17	1	61400343	Complete tank		Agosto 2020 / August 2020		BT3-147-09/20
18	1	61070011AR	Breather valve				
19	1	61380111R	Breather fuel pipe				
20	1	61380112R	Tube				
21	1	3073021AR	Tube		Agosto 2020 / August 2020		BT3-147-09/20
22	1	4161211R	Bush				
23	1	61400183	Gasket set				
24	1	61070079AR	Tank cap				
25	1	61070006R	Gasket				
26	1	61110162BR	Bushing				
27	1	61400322R	Fuel filter				
28	1	61070015R	Spacer				
29	1	61400077R	Support				
30	4	3918010R	Washer				
31	4	3819006R	Washer				
32	1	61400229R	Air filter	SN 2848080001			BT3-140-03/18
33	1	61400261A	Air filter cover + air filter	SN 2848080001			BT3-140-03/18
34	1	61400346	Diode Kit	Giugno 2020 / June			BT3-146-05/20
35	1	61400343	Complete tank	Settembre 2020 / September 2020			BT3-147-09/20
36	1	3073021AR	Tube	Settembre 2020 / September 2020			BT3-147-09/20
37	4	61400321R	Spacer	Settembre 2020 / September 2020			BT3-147-09/20
38	4	3891048R	Screw		Agosto 2020 / August		BT3-147-09/20
41	4	3891057R	Screw	Settembre 2020 / September 2020			BT3-147-09/20



LOBEST Kft.
Kertigépek és alkatrészek

WWW.LOBEST.HU

Illustration Transmission






Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61112072BR	Bevel gear Ø32				
2	1	3024012R	Snap ring				
3	1	3024012R	Snap ring				
4	1	3034019R	Bearing				
5	1	4138311A	Ring				
6	1	3025009	Ring				
7	1	3801016R	Screw				
8	1	61040071R	Cap				
9	1	-	Not available for this product				
10	1	3034218R	Bearing				
11	1	61110072R	Shaft				
12	1	3034012R	Bearing				
13	1	3025022R	Snap ring				
14	1	4138668	Spacer				
15	1	3050023R	Seal ring				
16	1	4191247R	Hub				
17	1	4179088R	Flange				
18	1	61110074AR	Guard				
19	1	61110075R	Nut				
20	1	3035023R	Bearing				
21	1	61112058	Bevel gear set				
22	1	61112166R	Complete clamp				
23	4	3801017R	Screw				
24	4	3819006R	Washer				
25	1	61110249R	Cover				
26	4	3801015R	Screw				
27	2	4098800BR	Insert				
28	4	3914003R	Nut				
29	1	61110250R	Hub				
30	1	61110251R	Clamp				
31	2	3819010R	Washer				
32	2	3801026R	Screw				
33	1	4098116R	Drive shaft				
34	1	61400206AR	Tube Ø32				
35	1	4174108R	Band				
36	1	4095033AR	Knob				
37	1	61170132R	Grommet				
38	1	61110205R	Handle and knob				
39	1	61040140R	Knob				
40	1	3914003R	Nut				
41	1	56550185R	Button				
42	1	61400301BR	Throttle cable				
43	1	4100098BR	Spring				
44	1	61400306R	Cable			Con tubo corrugato; With corrugated tube	

Illustration Transmission

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	61370114R	Lever				
46	1	61370294	Lever group				
47	1	61380064R	Throttle lever				
48	5	3893016AR	Screw				
49	1	3891054R	Screw				
50	1	61380097	Pair of handles				
51	1	61400188A	Handle kit				
52	1	61400310B	Throttle kit				
53	1	4174338A	Pin set				



WWW.LOBEST.HU



LOBEST Kft.
Kertigépek és alkatrészek


WWW.LOBEST.HU

Illustration Accessories

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	3960040R	Screw				
2	1	4174278R	Plate				
3	4	3802004DR	Screw				
4	1	61380126	Skirt w/blade				
5	1	4174275R	Blade				
6	1	61380125	Guard kit				
7	1	4191240	Tool kit				
8	1	61400192	Labels kit				
9	1	4095665BR	3-tooth blade				
10	1	63070003AR	Harness				
11	1	3065001	Hook				



WWW.LOBEST.HU



WWW.LOBEST.HU

Illustration Carburetor WT-1199

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318643R	Adjust. screw MAX				
2	1	2318671	Repair kit				
3	1	2318662BR	Carburetor				
4	1	3052036R	Special screwdriver "D-style" type				
5	1	2304001R	Special screwdriver KNURL-STYLE				EI02-02_22



WWW.LOBEST.HU




Illustration Illustrated parts list (Head "Load and Go" Ø130)

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	63129015	Head Load&Go			ExtraLife	
1	1	63129008	Head Load&Go			Easy&LongLife	
2	1	63120041R	Insert				
3	1	63120040R	Nut				
4	1	63120031R	Kit spring				
5	1	63120020AR	Ignition coil				
6	1	63120030AR	Knob			ExtraLife	
6	1	63120007AR	Knob			Easy&LongLife	
7	2	63120001R	Bushing				
8	1	63120005R	Cover				



WWW.LOBEST.HU